

RIDE QUALITY ASSESSMENT USING PROBE VEHICLE ACCELERATION MEASUREMENTS

Samer Katicha Senior Research Associate Center for Sustainable Transportation Infrastructure Virginia Tech Transportation Institute



Probe Vehicle Concept

WORLD ROA MONDIALE DE LA ROUTE

Fleet of on-road vehicles collect road data in real-time.

Could include a fleet of instrumented vehicles or integrated production models used by normal drivers.





Probe Vehicle Potential Benefits

- **Wider coverage on networks**
- ☑ Low cost per unit of data

WORLD ROAD

- Continuous and automated data collection
- ☑ No traffic disruptions
- Better representation of actual driver perception

Experiment

- Acceleration measurements taken from a Ford Fusion and a Volvo Truck.
- Profile data taken from a laser-profiler on the Virginia Smart Road.
- ☑ Acceleration and profile data repeatability
- ☑ Effect of test speed on vehicle vertical acceleration
- ☑ Effect of vehicle type on vehicle vertical acceleration
- ☑ Identification of rough spots

WORLD ROAD

Evaluating Ride Quality

- **☑** Typically referred to as smoothness or roughness.
- ☑ Computed by measuring vertical deviations in surface.
- ☑ Measured by high speed laser profilers.
- ☑ Quantified using the International Roughness Index





NORLD ROAI

Relation to Acceleration

- ☑ Road profile measures vertical variations in pavement.
- ☑ These variations are experience by vehicle.
- ☑ Vehicle accelerometers can document these changes.
- ☑ Bumpy areas of pavement display larger accelerations.





Virginia Smart Road





Smoothness Comparison





Repeatability (Ford Fusion)





Cross-Correlation

WORLD ROAD ASSOCIATION MONDIALE DE LA ROUTE

- **☑** Used to verify the similarity of two waveforms.
- ☑ Amount of shifting that optimizes the cross-correlation is utilized to more accurately match waveforms.

$$\varphi_{xy}(m) = E[x_n y_{n+m}] = \lim_{L \to \infty} \frac{1}{L} \sum_{n=0}^{L-1} x_n y_{n+m};$$



Cross-Correlation





WORLD ROAD ASSOCIATION MONDIALE DE LA ROUTE

Acceleration Repeatability

Measurement Type	Test Runs Compared	Value (g)
Standard Deviation of Differences	Runs 1 and 3	0.0244
Standard Deviation of Differences	Runs 2 and 3	0.0206
Standard Deviation of Differences	Runs 4 and 3	0.0224
Variance of Differences	Runs 1 and 3	0.00053984
Variance of Differences	Runs 2 and 3	0.00042248
Variance of Differences	Runs 4 and 3	0.00050327

Signal to Noise Ratio

- Std of Measurements divided by std of the difference between 2 measurements
 - ☑ Ford Fusion: 1.73
 - **☑** Profiler: 1.16

WORLD ROAD ASSOCIATION MONDIALE DE LA ROUTE

- ☑ Volvo Truck: 0.73
- Quality of measurement





Effect of Speed





Effect of Speed



Effect of Speed

- **10-90th Percentile Ranges** $\mathbf{\nabla}$
 - \square 40 MPH = 0.0551 g

MONDIALE DE LA ROUTI

- ☑ 50 MPH = 0.0783 g
- \boxtimes 65 MPH = 0.1340 g





Effect of Vehicle Type





Effect of Vehicle Type





Effect of Vehicle Type

- ☑ 10-90th Percentile Ranges (at 50 MPH)
 - **☑** Ford Fusion = 0.0783 g

WORLD ROAD

ELAROU

- ☑ Volvo Truck = 0.1189 g
- ✓ Average Acceleration (at 50 MPH)
 ✓ Ford Fusion = 0.0319 g
 ✓ Volvo Truck = 0.0478 g



Acceleration Analysis

WORLD ROAD ASSOCIATION MONDIALE DE LA ROUTE

Maintenance strategies can tailor roughness thresholds to meet needs by section or spot location.



Conclusions

WORLD ROAD

- ☑ Ride quality (smoothness) is a promising application of probe vehicles.
- Acceleration measurements exhibit an acceptable level of repeatability.
- ☑ Acceleration is sensitive to vehicle speed, type.
- Rough sections of pavement can be identified using threshold values.



Norfolk, Virginia / September 19-22, 2012 7th symposium on pavement surface characteristics

Questions?